

A GUIDE ROD FOR RELEASER

- Improved rod guide with seal
- Improves the tightness of the device
- Installs on any new device and existing ones
- When installing a changemente the float rod is mandatory when installing the guide
- Daily maintenance required (Product code in store)

POUR COMMANDER CONTACTEZ / TO ORDER CONTACT:

MONTREAL & EAST COAST

1.866.351.2811

info@dominiongrimm.ca

ONTARIO & WEST COAST PACKAGING

1.877.676.1914

heather@dominiongrimm.ca

DG USA

1.802.524.9625

(Owen) omanahan@dominiongrimm.ca